



Product information

CARUS IRIS

Video front-door station for surface-mount

CAE200x-015x



Table of contents

Scope of delivery.....	4
introduction.....	4
Notes on this product information	4
Further used symbols	4
Safety instructions.....	5
General safety regulations.....	5
requirements to protect against lightning.....	5
Product description	6
Intended use	6
Short description	6
Device overview.....	7
Technical data	8
Mounting and installation	9
Installation	9
<i>Installation site.....</i>	<i>9</i>
<i>Opening the device.....</i>	<i>9</i>
<i>Installing the bottom shell.....</i>	<i>11</i>
<i>Connecting the lines.....</i>	<i>11</i>
<i>Fixing the top shell.....</i>	<i>12</i>
<i>Labelling the nameplate.....</i>	<i>13</i>
<i>Closing the device</i>	<i>13</i>
Connecting the lines.....	14
<i>General information</i>	<i>14</i>
Example circuit	14
Initial operation.....	15
Settings.....	15
<i>Setting the volume of the system tone</i>	<i>15</i>
<i>Setting the volume of the loudspeaker</i>	<i>15</i>
<i>Setting the illumination</i>	<i>15</i>
Programming the bell buttons.....	16
Basic principle.....	16
Cleaning	18
Conformity	19
Information on disposal.....	19
Warranty	19
Service.....	20

Scope of delivery

- 1 x IRIS front-door station
- 1 x slot screwdriver
- 1 x hexagon ballpoint screwdriver with 2.5 mm wrench size
- 1 x installation kit (universal dowel 6 x 35 mm and chipboard screw PZ 3.5 x 40 mm)
- 2 x laser film foil matt, format DIN A4 for name plates
- 1 x product information

introduction

Notes on this product information



This product information refers exclusively to qualified electricians.

The product information contains important notes on intended use, installation and initial operation. Please keep the product information in a suitable place, where it is easily accessible for maintenance and repair reasons. You will find all product information in the download area at www.carus-concepts.com.

Used symbols and warning notices

Symbol	signal word	Explanation
	DANGER!	The signal word describes an endangering with a high level of risk. Failure to observe this warning will result in death or very serious injury.
	WARNING!	The signal word describes an endangering with a medium level of risk. Failure to observe this warning could result in death or very serious injury.
	CAUTION!	The signal word describes an endangering with a low level of risk. Failure to observe this warning could result in a minor or moderate injury.
	ATTENTION!	The signal word indicates, that damages on equipment, environment and property can occur.

Further used symbols



important note or important information



Step



cross reference: For further information on this topic, refer to source



list, list entry 1 level



list, list entry 2 level



Explanation

Safety instructions

General safety regulations



Assembly, installation, commissioning and repair of electronic devices must be carried out by qualified electricians.

Observe the latest regulations and standards for system installations.



WARNING! Danger to life from electric shock

Observe the safety regulations according to DIN VDE 0100, when working on main power connections of 230 V.



When installing TCS:BUS systems the general safety regulations for telecommunication systems according to VDE 0800 must be observed. Inter alia:

- separated cable routing of high and low voltage lines,
- minimum distance of 10 cm in case of a common cable routing,
- use of separators between high and low voltage lines within shared cable ducts,
- use of standard telecommunication lines, e.g. J-Y (St) Y with 0.8 mm diameter,
- already existing lines (modernisation) with deviating cross-sections can be used in compliance with the loop resistance.

requirements to protect against lightning



ATTENTION!

Device damage due to overvoltage.

By suitable lightning protection measures it has to be ensured that the electric voltage of 32 V DC at each connection is not to be exceeded.

Product description

Intended use

The CAE200x-015x video front-door stations are suitable for outdoor use.
They are suitable for surface-mount.




For applications, which differ from the intended use or goes beyond it, the manufacturer accepts no liability.

Short description

- Front-door station for surface-mount
- for up to 3 flats
- housing made of solid aluminium
- surface with hand-made grinding and elaborate finishing (colour: black or silver)
- illuminated and chrome-plated bell buttons made of metal with maintenance-free contacts
- per bell button 2 indoor stations can be allocated
- durable and energy-saving name plate illumination
- name plate illumination is controlled by twilight switch
- threshold of the twilight switch can be adjusted manually
- acknowledgement tone when pressing the bell button
- volume system tones can be adjusted manually
- conversation time ex works: 56 seconds / can be adjusted with service device TCSK
- any bell button can be used to switch lights
- volume loudspeaker can be adjusted manually
- R-terminal for connection of an extended function *door release*
- door release time at R-terminal ex works: 3 seconds / can be adjusted with configuration software configo™
- door call standby time (to control the short-term memory in indoor stations) ex works: 56 seconds / can be adjusted with configuration software configo™
- voice connection in door call standby time / can be adjusted with service device and configuration software configo™
- CMOS camera with 1.3 mega pixel
- wide-angle lens, horizontal detecting angle (F.O.V) 180°
- focal length F2.0
- digital image correction
- video signal output symmetric 1 Vss FBAS
- based on the TCS video system with 6-wire technique

Device overview



front

- 1 top shell
- 2 camera
- 13 bell button
- 14 nameplate
- 15 release screw for name plate holder
- 16 loudspeaker

back

- 3 volume control system tones
- 4 volume control loudspeaker
- 5 LED error indication
- 6 controller light sensor (twilight switch)
- 7 connection terminal (a, b, R, P, M, V1 and V2)
- 8 type label
- 9 locking hexagon socket screw
- 10 label connections and operation
- 11 connection for service device
- 12 microphone

Technical data

supply voltage	+24 V \pm 8 % (power supply and control unit)	
input current in stand-by	3-wire operation:	I(a) = 0.1 mA, I(P) = 103 mA
max. input current:	I(a _{max}) = 14.8 mA , I(P _{max}) = 120 mA	
housing	aluminium, anodised natural / silver or black	
nameplate glass	acrylic glass	
dimensions (in mm)	H 330 x W 150 x D 27	
weight	2160 g	
acceptable ambient temperature	-20 °C ... + 50 °C	
degree of protection	IP44	
camera	colour camera	1.3 mega pixel CMOS sensor
	detection angle	180°
6-wire technique necessary!		

Mounting and installation

Installation

For installing the bottom shell use the installation kit (enclosed in the delivery).



- Condensed water must be able to escape and evaporate. Avoid closing the opening for condensed water.
- Do not seal the device with silicone rubber under any circumstances.

Installation site

For an optimal operation we recommend a mounting height of 160 cm (camera above ground, ill. 1).



For changing the nameplate pull the nameplate holder (1) downwards.
Observe a free space of **at least 13 cm**.



To achieve a high quality of the video image, the camera must not be oriented towards direct sunlight.

- solar radiation
- strong sources of light
- light or strongly reflecting walls.




Fig. 1: mounting height

Opening the device

The nameplate holder (2) is screwed to the housing (1) with an hexagon socket screw (3).

- Remove the hexagon socket screw (3) by using the allen key (4) (ill. 2).



The nameplate holder is secured from falling down by two solenoids.




Fig. 2: Opening the front-door station

- Pull out the nameplate holder **(1)** (ill. 3).
- Place the nameplate holder on a clean and dry surface.




Fig. 3: Removing nameplate holders

The top shell is connected to the bottom shell with another hexagon socket screw.

- Loosen the hexagon socket screw **(1)** by using the allen key (ill. 4).




Fig. 4: Loosen the top shell

- Remove the top shell **(1)** from the bottom shell **(2)** (ill. 5).
- Place the top shell on a clean and dry surface.




Fig. 5: Removing the top shell

Installing the bottom shell

- Puncture the cellular rubber seal with a pointed object at the position of the cable gland.
- Guide the connection cable (3) through the cable gland (2) of the bottom shell (ill. 6).
- Install the bottom shell with 4 screws (1) (enclosed in the delivery) to the wall.



Observe the installation position of the bottom shell. The installation position of the bottom shell is marked by two arrows as well as the designation *Oben Top*.




Fig. 6: Fixing the bottom shell on the wall

Connecting the lines

- Draw off the connection terminal (2) from the circuit board.
- Strip the lines.
- Connect the lines (a, b, P, M, V1 and V2) according to the labelling (1) (ill. 7).
- Fix the lines by using the screwdriver (3) (enclosed in the delivery).



Observe the example circuit on page 14.




Fig. 7: Connecting the lines

- Pin the connecting terminal (1) on the circuit board again (ill. 8).




Fig. 8: Pin the connecting terminal

Fixing the top shell

- Put on the top shell **(1)** on the bottom shell **(2)** (ill. 9). The fixing brackets have to latch over the upper edge of the bottom shell.
- Turn down the top shell on the bottom shell.




Fig. 9: Installation of the top shell

- Fix the top shell with the hexagon socket screw **(1)** at the bottom shell (ill. 10).



Fig. 10: Secure the top shell

Labelling the nameplate



Labelling templates as WORD files are available for download at www.carus-concepts.com.

- ▶ Enter the required names into the labelling template.
- ▶ Print the nameplates on the special foil (enclosed in the delivery) by using a laser printer.
- ▶ Alternatively label the special foil with a waterproof marker.
- ▶ Cut out the foil along the marking (W x H 72 x 77 mm).
- ▶ Push the nameplate from the side into the gap in the nameplate glass (ill. 11).



we recommend to print the nameplates onto a durable special foil.

- ▶ You can order replacement foils directly under [in-fo@carus-concepts.com](mailto:info@carus-concepts.com).



Fig. 11: Replacing nameplates

Closing the device

- ▶ Push the nameplate holder into the front-door station (see p. 10, ill. 3).
- ▶ Fix the nameplate holder with the hexagon socket screw M3x10 (ill. 12).



Fig. 12: Closing the device

Connecting the lines

General information



- Use the small slot screwdriver (enclosed in the delivery) to connect lines. Avoid damaging the device.
- Ensure that no lines are clamped on the backside of the front-door station or between top and bottom shell.

Example circuit




Fig. 13: Example circuit

For further information see TCS system manual. The TCS system manual can be downloaded at www.tcsag.de.

Initial operation

- ▶ Install the devices of the system completely.
- ▶ Proof the a-, b- and P-wire against each other on short-circuit.
- ▶ V1 and V2 must not be connected with the P-, a- or b-wire.
- ▶ When connecting the video wires V1 (+) and V2 (-) the polarity must be observed.
- ▶ Switch on the mains voltage.

Settings



- For setting the volume use the enclosed slot screwdriver.
- The volumes are set on an average value ex works. A change is not always required.

Setting the volume of the system tone

- ▶ Turn the control **(1)** right to increase the volume of the key tone.
- ▶ Turn the control **(1)** left to reduce the volume of the key tone.




Fig. 14: Setting the volume of the system tone

Setting the volume of the loudspeaker

- ▶ Turn the control **(2)** right to increase the volume of the voice output.
- ▶ Turn the control **(2)** left to reduce the volume of the voice output.




Fig. 15: Setting the volume of the loudspeaker

Setting the illumination

By using the twilight switch you can control the illumination of the front-door station. The threshold is set to middle twilight ex works.

- ▶ Turn the control **(3)** right to increase the threshold.
- ▶ Turn the control **(3)** left to reduce the threshold.



If the front-door station should be illuminated permanently, turn the control to the left until the stop.




Fig. 16: Setting the illumination

Programming the bell buttons

Basic principle

All devices at the TCS:BUS have an unique serial number.

The serial number of the indoor station is allocated to the bell button of the front-door station. The allocation is stored in the EEPROM of the front-door station.

Requirements for the programming:

- ▶ Ensure that the access to the indoor station in the flat is granted.
- ▶ Check if the indoor station is connected to the TCS:BUS.
- ▶ Switch on the mains voltage. The operating LED at the power supply and control unit is on.
- ▶ Check if a programming lock is set.



 *Manual TCSK.*



If a programming lock is set, you cannot program any bell button.

To deactivate the programming lock you need a Service Device TCSK or the configuration software configo™.

1 power supply and control unit Switch on the programming mode of the system




Shortly press ^{a/} the RUN/PROG button.

The LED blinks.

The programming mode of the system is switched ON.

2 Deleting bell buttons ^{b/}



Press the button which should be deleted for 6 seconds until an acknowledgement tone sounds. ^{c/}

Release the bell button.
Repeat step 2 to delete further bell buttons.

3 Programming via voice communication



Establish a voice communication to the front-door station. ^{d/} Press the bell button which should be programmed. A ring tone sounds at the front-door and indoor station. ^{d/} Terminate the voice communication.

4 power supply and control unit Switch off the programming mode of the system



Shortly press the RUN/PROG button. The LED is on. The programming mode of the system is switched OFF. ^{e/}

- a) Do not press the RUN/PROG button longer than 5 seconds. Otherwise you will activate the light switch function of the front-door station. The bell button cannot be programmed. The LED blinks. Shortly press the RUN/PROG button to switch off the programming mode. Shortly press the RUN/PROG button to switch on the programming mode. Program the bell button.
- b) If the light switch function is activated, you can switch the lights by pressing the door release button of the indoor station, if no voice communication is established. Switch on the programming mode. Press the RUN/PROG button longer than 5 seconds until the LED lights up. The light switch function is deactivated.
- c) Not necessary, if the bell buttons have not been programmed, see product information of the front-door station.
- d) If there sounds a Progsper tone (long high tone followed by long low tone) instead, the front-door station is equipped with a programming lock. You can deactivate the programming lock only with the service device TCSK or the configuration software configo™.
- e) An acknowledgement tone sounds at front-door stations (as of 2009) if the serial number of the indoor station was received (see product information of the front-door station).
- f) device specific indication modes of the front-door station see product information of the font-door station

Cleaning



ATTENTION!

Loss of function due to short-circuit and corrosion.

Water and cleaning agents can enter the device. Electronic elements can get damaged due to short-circuit or corrosion.

Avoid water and detergents from entering the device! Clean the device with a dry or slightly wet cloth.



ATTENTION!

Damages on the surface of the device

Abrasive or scratching detergents damage the surface of the device.

Do not use any abrasive detergents! Remove stronger stains with a pH neutral household cleaner.

Conformity



Declarations of conformity are available for download under www.tcsag.de.

Information on disposal



Dispose the device separately from domestic waste via a collection point for electronic scrap. Ask your county administration for the responsible collection point.



Dispose the parts of the packaging in collecting tanks for cardboard and paper resp. plastics.

Warranty

We offer **a simplified processing** in case of warranty for qualified electricians.

- Please contact the **TCS HOTLINE** under hotline@tcsag.de.
- Our **standard terms and conditions of sale** you'll find under www.tcsag.de.

Service

Please send your questions and inquiries to
hotline@tcsag.de

Headquarters

TCS TürControlSysteme AG, Geschwister-Scholl-Str. 7, 39307 Genthin | Germany
FON: +49 (0) 3933/8799-10, FAX: +49 (0) 3933/879911, www.tcsag.de

Subject to technical changes.

TCS Hotline Germany

FON: +49 41 94 / 9 88 11 88, Fax: +49 41 94 / 9 88 129 Mail: hotline@tcsag.de

time of printing: 06/2015
PI_CAE200x-015x_uk 1 A